

CABLE MATRIX FOR HHS GENERAL PURPOSE PRODUCTS



Type	Description	Note	P/N	Touch Lite USB	Touch Lite KBW+RS232	TOUCH Pro HERON G HERON D130 GRYPHON D/M 130/230 GRYPHON D432/Plus FIRESKAN D131 QUICKSCAN M2130	HERON D110 GRYPHON D110 GRYPHON D412	GD4130 QD2130	QD2330	QM2110 Gryphon D412+ GD4110 QD2110	HERON D140 FIRESKAN D141
RS232	Straight	CAB-350 RS232 PWR STR. 9PIN FEM.	9 PIN Female, Powered	90A051230		■	■	■	■	■	
		CAB-327 RS232 STR. 9PIN FEM.	9 PIN Female	90G001070		■	■	■	■	■	
		CAB-328 RS232 STRAIGHT 25PIN FEM. DCE	25 PIN Female, DCE	90G001080		■	■	■	■	■	
		CAB-320 RS232 STRAIGHT 25 PIN DTE	25 PIN Male, DTE	90G001000		■	■	■	■	■	
	Coiled	CAB-362 RS232 COILED 9PIN FEM.	9 PIN Female	90A051330		■	■	■	■	■	
		CAB-363 RS232 COILED 25PIN FEM. DCE	25 PIN Female, DCE	90A051340		■	■	■	■	■	
		CAB-408 RS232 PWR COIL9PIN FEM	9 PIN Female, Powered	90A051891		■	■	■	■	■	
CAB-364 RS232 COILED 25PIN MALE DTE	25 PIN Male, DTE	90A051350		■	■	■	■	■			
IBM46XX	Straight	CAB-370 Straight Cable – 9B Port		90A051420			■				
		CAB-445 IBM 46XX PORT 5 CABLE		90A051977						■	
		CAB-446 IBM 46XX PORT 9 CABLE		90A051978						■	
Wedge	Straight	CAB-321 IBM PS/2 STR. MINIDIN WEDGE	IBM PS/2 MINIDIN	90G001010		■	■	■	■		
		CAB-322 IBM AT/XT STR. DIN WEDGE	IBM AT/XT DIN	90G001020		■	■	■	■		
		CAB-324 IBM vdt. 31xx, 32xx, 37xx	Din 240° Connector	90G001040		■	■	■	■		
		CAB-325 IBM vdt. 3151, 34xx	8-pin Telephone Connector	90G001050		■	■	■	■		
		CAB-373 WYSE VDT 60/120/160/185/370 Straight	4-pin Telephone Connector	90A051470		■	■	■	■		
	CAB-375 DEC VDT VT200/220/ 240/300/320/340/420 Straight	4-pin Telephone Connector	90A051490		■	■	■	■			
	Coiled	CAB-365 IBM PS/2 COILED MINIDIN WEDGE	IBM PS/2 MINIDIN	90A051360		■	■	■	■		
CAB-391 IBM PS/2 Wedge Minidin Coiled Cable		IBM PS/2 MINIDIN	90A051740		■	■	■	■			
Wand	Straight	CAB-323 WAND EMUL. STR. 9PIN MALE	9 PIN Male	90G001030		■	■	■			
		Coiled	CAB-348 WAND EMUL. COIL. 9 PIN MALE	9 PIN Male	90A051210		■	■	■		
USB	Straight	CAB-412 USB TYPE A	USB TYPE A, Powered	90A051902	■		■				
		CAB-413 USBIBM POS Mode	USB TYPE A	90A051903	■		■	■	■	■	
		CAB-426 USB TYPE A	USB TYPE A	90A051945	■		■	■	■	■	
TTL	Coiled	CAB-397 TTL/LASER COILED 9P MALE	9 PIN Male	90A051820							■

CABLE MATRIX FOR HHS INDUSTRIAL PRODUCTS



Type	Description	Note	P/N	PD7130	PD7110	PD8330 BC8030	BC8060	PD8340	PD8530	
RS232	Straight	CAB-433 RS232 PWR 9P FEM STRAIGHT	9 PIN female connector; POT on pin 9 or through external Power Supply; 6'	CAB-433	■	■	■	■		■
		CAB-501 RS232 PWR 9P FEM STRAIGHT	9 PIN female connector; POT on pin 9 or through external Power Supply; 10.5'	CAB-501	■	■	■	■		■
		CAB-450 RS232 X MOTOROLA VRC69xx	Connection to SYMBOL VRC69XX Terminal, 16 Pin "Fisher" connector, 12'	CAB-450	■	■	■	■		■
	Coiled	CAB-434 RS232 PWR 9P FEM COILED	9 PIN female connector; POT on pin 9 or through external Power Supply; 8'	CAB-434	■	■	■	■		■
		CAB-459 RS 9P FEM COIL	9 PIN female connector; POT on pin 9 or through external Power Supply; 12'	CAB-459	■	■	■	■		■
		CAB-479 RS232 9P FEM COIL	9 PIN female connector; POT on pin 9 or through external Power Supply; 25'	CAB-479	■	■	■	■		■
		CAB-471 RS232 25PIN FEM. DCE COILED	25 PIN female connector; POT on pin 25 or through external Power Supply. DCE pinout; 10'	CAB-471	■	■	■	■		■
		CAB-477 RS232 25P FEM DCE COILED	25 PIN female connector; POT on pin 25 or through external Power Supply. DCE pinout; 25'	CAB-477	■	■	■	■		■
		CAB-472 RS232 25PIN MALE DTE COILED	25 PIN male connector; POT on pin 25 or through external Power Supply. DTE pinout; 10'	CAB-472	■	■	■	■		■
		CAB-474 RS PWR 25P FEM DTE COIL	Serial cable, null modem, POT on pin 25 or through external Power Supply, 12'	CAB-474	■	■	■	■		■
Wedge	Straight	CAB-436 WEDGE PS/2 STRAIGHT	PS/2 MINIDIN; 6'	CAB-436	■		■	■		
		CAB-442 WEDGE PS/2 STRAIGHT EXT.PWR	PS/2 MINIDIN; External Power Supply required. Necessary for 8500 models	CAB-442						■
	Coiled	CAB-437 WEDGE PS/2 COILED	PS/2 MINIDIN; 10'	CAB-437	■		■	■		
		CAB-462 KBW PWR PS/2 COIL	PS/2 MINIDIN; 12'	CAB-462	■		■	■		
USB	Straight	CAB-438 USB TYPE A STRAIGHT	USB TYPE A; 6'	CAB-438	■	■	■	■		
		CAB-465 USB TYPE A STRAIGHT	USB TYPE A; 12'	CAB-465	■	■	■	■		
		CAB-440 USB TYPE A STRAIGHT EXT.PWR	USB TYPE A. External Power Supply required. Necessary for 8500 models	CAB-440						■
	Coiled	CAB-439 USB TYPE A COILED	USB TYPE A; 8'	CAB-439	■	■	■	■		
CAB-467 USB TYPE A COIL FULL SP		USB TYPE A; 12'	CAB-467	■	■	■	■			
Wand	Coiled	CAB-486 IBM USB 12V COIL	Powered USB; 15'	CAB-486	■	■	■	■		
		CAB-441 USB TYPE A COILED EXT.PWR	USB TYPE A. External Power Supply required. Necessary for 8500 models	CAB-441						■
		CAB-470 WAND EMUL. 9P MALE STRAIGHT	9 PIN Male connector (legacy Datalogic pinout for DLD1000;DPS8000/9000); 6'	CAB-470	■		■	■		
		CAB-487 WAND RJ6 COIL	RJ45 6 Pin; 8'	CAB-487	■		■	■		
		CAB-488 WAND RJ6 DECATH COIL 20'-6.1m	RJ45 6 Pin; 20'	CAB-488	■		■	■		
		CAB-489 WAND LEMO-7M LXE COIL	7 Pin Male LEMO connector; 8'	CAB-489	■		■	■		
TTL	Coiled	CAB-490 WAND 9P FEM COIL 15'-4.6m	9 Pin Female; 15'	CAB-490	■		■	■		
		CAB-491 WAND RJ10 INTERC2010 8'-2.4m	RJ45 10 Pin for Intermec 5020, 9710, 9720, 9730, 2010, T2455 & T2481; 8'	CAB-491	■		■	■		
		CAB-473 WAND EMUL. 9P MALE COILED	9 PIN Male connector (legacy Datalogic pinout for DLD1000;DPS8000/9000); 8'	CAB-473	■		■	■		
IBM46xx	Coiled	CAB-505 TTL/LASER COIL	9 PIN Female connector (legacy PSC pinout for INTERMEC/NORAND terminal type 1700; Compsee QR;PowerWedge); 12'	CAB-505					■	
		CAB-468 SH4116	8 pin "Fisher" connector for Symbol VRC 6940; 8'	CAB-468-C003					■	
		CAB-468 TTL/LASER 9P MALE COILED	9 PIN Male connector (legacy Datalogic pinout for DLD1000;DPS8000/9000); 6'	CAB-468					■	
RS485 adapter	Straight	CAB-469 IBM46xx 9B POT	IBM46xx POS cash register, Port 9B; 12'	CAB-469		■				
	Straight	CAB-428 RS485 INTERFACE SPLITTER	2 x 4 PIN RJ Female. RS485 line splitter for cradle networking	90A051950				■		